

**POSTUPAK PODEŠAVANJA FOTOKLOPKE**

1. U fotoklopku ubacimo SD karticu i baterije
2. Prekidač ostavimo u položaju „OFF“
3. Uz pomoć USB kabla (sastavni deo isporuke) povežemo PC sa fotoklopkom
4. Uključimo u PC program podešavanja – „SETUP“.
5. Pritisnemo „CAMERA SETUP“.
6. Izvršimo osnovno podešavanje fotoklopke.
7. Posle podešavanja pritisnemo dugme „SELECT“ – odaberemo SD karticu fotoklopke napr. G:/ i pritisnemo „OK“, pored tastera „SELECT“ se promeni slovo na G:/.
8. Pritisnemo taster „GENERATE“ i podešavanje je sačuvano na SD kartici (G:/).

Kada u PC pogledamo SD karticu (G:/) vidimo fajlove „xx.dat“.

9. Fotoklopku isključimo od PC, prebacimo na položaj „TEST“ i tokom uključenja se na monitoru pojavi „menu.dat.succesfully“ i na osnovu toga vidimo da se u fotoklopku snimila podešena konfiguracija.
10. Podešena konfiguracija je sačuvana na SD kartici do sledeće izmene, može da se pregleda u „MENU“.

**POSTUPAK PODEŠAVANJA MMS**

**(kod modela 6210MG)**

1. U fotoklopku ubacimo SD karticu, SIM karticu i baterije
2. Prekidač ostavimo u položaju „OFF“
3. Uz pomoć USB kabla (sastavni deo isporuke) povežemo PC sa fotoklopkom
4. Uključimo u PC program podešavanja – „SETUP“.
5. Pritisnemo „CAMERA SETUP“.
6. Izvršimo osnovno podešavanje fotoklopke.
7. Posle podešavanja pritisnemo dugme „SELECT“ – odaberemo SD karticu fotoklopke napr. G:/ i pritisnemo „OK“, pored tastera „SELECT“ se promeni slovo na G:/.
8. Pritisnemo taster „GENERATE“ i podešavanje je sačuvano na SD kartici (G:/).
9. Pritisnemo „MMS SETUP“
10. Iz AUTO prebacimo na Manual.
11. Prema mobilnom operatoru popunimo podatke
  - 1) Telekom:  
APN: mms  
Username: mts  
Password: 064  
Proxy address: 172.017.085.131

**Port: 8080**

**Homepage: <http://mms.mts064.telekom.rs/mms/wapenc>**

Ltl Acorn 6210

MMS

MMS Mode **Manual** MMS Status **VGA**

Picture No./day **0** Note: 0 = Unlimited

Country **Other** Operator **Other**

SMS Remote Control **Off** H

URL **http://mms.mts064.telekom.rs/mms/wapenc**

APN **mms**

Gateway **172.017.085.131**

Port **8080**

Phone No **0652470170** Domestic

Email

Account **mts**

Password **064**

Phone or Email

Phone or Email

Select C:\

Generate Exit

2) **Telenor:**

**APN: mms**

**Proxy address: 217.065.192.033 (ili 217.65.192.33)**

**Port. 8080**

**Homepage: <http://mms.telenor.rs/servlets/mms>**

Ltl Acorn 6210

MMS

MMS Mode: Manual MMS Status: VGA

Picture No./day: 0 Note: 0 = Unlimited

Country: Other Operator: Other

SMS Remote Control: Off H

URL: http://mms.telenor.rs/servlets/mms

APN: mms

Gateway: 217.65.192.33

Port: 8080

Phone No: 0652470170 Domestic

Email:

Account:

Password:

Phone or Email:

Phone or Email:

Select: G\1

Generate Exit

- 3) **VIP:**  
**APN: vipmobile.mms**  
**Username: vipmobile**  
**Password: vipmobile**  
**Proxy address: 212.15.182.82**  
**Port: 8080**  
**Homepage: <http://mms.vipmobile.rs/>**



12. Posle podešavanja pritisnemo dugme „SELECT“ – odaberemo SD karticu fotoklopke napr. G:/ i pritisnemo „OK“, pored tastera „SELECT“ se promeni slovo na G:/.
13. Pritisnemo taster „GENERATE“ i podešavanje je sačuvano na SD kartici (G:/).
14. Fotoklopku isključimo od PC, prebacimo na položaj „TEST“ i tokom uključenja se na monitoru pojavi „menu.dat.succesfully“ i na osnovu toga vidimo da se u fotoklopku snimila podešena konfiguracija.
15. Podešena konfiguracija je sačuvana na SD kartici do sledeće izmene, može da se pregleda u „MENU“.

**Napomena:** Uverite se da Vaša SIM kartica omogućava slanje MMS poruka.

### POSTUPAK PODEŠAVANJA INTERNETA (kod modela 6210MG)

1. U fotoklopku ubacimo SD karticu, SIM karticu i baterije
2. Prekidač ostavimo u položaju „OFF“
3. Uz pomoć USB kabela (sastavni deo isporuke) povežemo PC sa fotoklopkom
4. Uključimo u PC program podešavanja – „SETUP“.
5. Pritisnemo „CAMERA SETUP“.
6. Izvršimo osnovno podešavanje fotoklopke.

7. Posle podešavanja pritisnemo dugme „SELECT“ – odaberemo SD karticu fotoklopke napr. G:/ i pritisnemo „OK“, pored tastera „SELECT“ se promeni slovo na G:/.
8. Pritisnemo taster „GENERATE“ i podešavanje je sačuvano na SD kartici (G:/).
9. Pritisnemo „SMP SETUP“
10. Iz AUTO prebacimo na Manual.
11. Prema mobilnom operatoru popunimo podatke – APN, Account, Password.

**NAPOMENA! VAŽNO!**

Za slanje slika sa fotoklopke preko interneta u Srbiji je neophodno da koristite račun kod Googla kod kojeg ćete isključiti podršku bezbednog priključenja.

Postupak isključenja podrške:

- 1) Prijavite se na račun kod Googla
- 2) Izvršite deaktivaciju na:

<https://www.google.com/settings/security/lesssecureapps>

**PREPORUKA:**

Za fotoklopku napravite posebnu adresu koja će biti korišćena samo za svrhe slanja poruka iz fotoklopke!

12. Popunite podatke za slanje preko interneta:

Smt Server:       smt.gmail.com  
Port:               465  
Semder Email:     [imegoogle@gmail.com](mailto:imegoogle@gmail.com)  
Password:         lozinka za navedenu adresu  
Email 01:         adresu primalaca

13. Posle podešavanja pritisnemo dugme „SELECT“ – odaberemo SD karticu fotoklopke napr. G:/ i pritisnemo „OK“, pored tastera „SELECT“ se promeni slovo na G:/.
14. Pritisnemo taster „GENERATE“ i podešavanje je sačuvano na SD kartici (G:/).
15. Fotoklopku isključimo od PC, prebacimo na položaj „TEST“ i tokom uključenja se na monitoru pojavi „menu.dat.succesfully“ i na osnovu toga vidimo da se u fotoklopku snimila podešena konfiguracija.
16. Podešena konfiguracija je sačuvana na SD kartici do sledeće izmene, može da se pregleda u „MENU“.

**NAPOMENA:**

Fotoklopka može uvek da se podesi na slanje poruka preko MMS ili preko interneta. Nije moguća zajednička opcija.